Week 5 – Sensors II

Advanced Mechatronics System Design – MANU2451

Dr Chow Yin LAI

Edited by Dr Milan Simic
School of Engineering
RMIT University, Victoria, Australia
Email: milan.simic@rmit.edu.au

PRINT University

PRINT University

PRINT University

New Teaching Schedule

Week	Class Activity Before	Lecture	Class Activity During or After
1		Introduction to the Course / Introduction to LabVIEW	LabVIEW Programming
2		Introduction to LabVIEW / Data Acquisition	LabVIEW Programming
3		Gripper / Introduction to Solidworks / Safety	Gripper Design
4		Sensors I	myRIO Programming for Sensor Signal Reading / Gripper Design
5		Sensors II	myRIO Programming for Sensor Signal Reading
6		Actuators I	LabVIEW Tutorial
7	LabVIEW Assessment.	DC Motors I	Matlab Simulink Simulation
8	Design report submission	DC Motors II	Matlab Simulink Simulation / myRIO Programming for Control
9		Actuators II	Matlab Simulink Simulation Gripper CAD
10		Modeling and System Identification	Matlab Simulink Simulation / Gripper simulation testing
11		Artificial Intelligence I	Matlab Simulation / Finalize Gripper
12	Gripper Simulation / Submission of Report	Artificial Intelligent II	Revision

Assessment 2020

- LabView assessment (Individual online Quiz) on week 7 (22/04) 20%
 Design assessment (Team) on Tuesday of week 8 (29/04) 10%
 - A brief written Report, with figures of the gripper assembly, and explanation of the components.
 - Also, explain choice of design, calculation etc.
- Submit Gripper Simulation Program and Report (Team) on week 12 (27/05)
 10% and 40% respectively.
 - · Report template is given in the course folder.
- Final exam (Individual) 20%
 - Online Quiz
 - Will be on Wednesday of Week 14.



Peer Assessment

Note that the team assignments, i.e.

- Design assessment (10%)
- Gripper demonstration and final report (50%)

will have a peer assessment component.


How it works:

- You will be given a group score after the initial marking.
- In Week 12 or 13, I will send out a questionnaire where you will be rated by other team members based on your participation and contribution.
- The final individual score will be then:
 - (group score) x (average rating by other team members).



Mechatronics System Components

D/A, Amplifier, PWM etc.



Project Options – Control Design

In a myRIO project, the program can run from three different "locations":

1. PC (host):

1. Suggested: For non-time-critical tasks such as complex UI to visualize data.

2. Real-time processor:

- 1. Suggested: For time-critical tasks which needs to run in real-time, i.e. cannot be interrupted by lower priority tasks (anti-virus, UI etc.)
- 2. Also for data logging, file management.

3. FPGA:

 Suggested: For tasks which are time-critical and has to be very fast, e.g. Accessing IO, PWM, reading encoder pulses, emergency stop.

In this online course, we will develop simulation program to run on

- PC (Option 1) or,
- myRIO real, or simulated (Option 2)
- Programming environment could be LabVIEW, MATLAB/Simulink, C/C++, JAVA, Pyton... // Objective is the <u>Development of Programming Mindset</u>
- CAD design will not be printed, just submitted

Notes on programming in FPGA will also be given but these are only for selfstudy. (Please refer to attachment).

Online Collaboration

- Collaboration
- Discussions
- Collaborate Ultra
- Microsoft Teams
- Skype
- Viber
- FaceTime
- Email
- •
- Teams and the team members / please send me email (just 11)




Sensors and Actuators

- Sensors and actuators are used to transform
 - signals and energy carried by a physical quantity
 of one kind
 - into signals and energy carried by a physical quantity of another kind.
- There are many different types of sensors and actuators in use.

Mechatronics System Components

D/A, Amplifier, PWM etc.





Mechatronics System Components

Sensors: Encoder at each joint



Industrial Robots

https://commons.wikimedia.org/wiki/File:Float_Glass _Unloading.jpg

Actuators:
Geared motor
at each joint

Input signal interfacing

Robot controller:

- Generate desired motion trajectory
- Calculate current end-effector position based on angular position (kinematics)
- Calculate desired angular position for desired endeffector position and trajectory (inverse kinematics)
- Control algorithm
- Safety, collision detection etc.




Output signal interfacing



Variety of Sensors

- Transducers
 - Motion
 - Temperature
 - Force
 - Stress
 - Flow
- Position sensing
- Laser Range Sensors
- Smart Sensors

Most Common Sensor Connection



Could be analogue or digital

Encoders, Gray Code Instead of Binary 0,1 00, 01, 11, 10 WHY?





Encoder

Content

- Position Measurement
 - Measure using myRIO
- Speed Measurement
- Vibration and Acceleration Measurement
- Stress and Strain Measurement
 - Measure using myRIO
- Saving (Sensor) Data using myRIO
- Attachment: Writing FPGA Codes



Content

- Position Measurement
 - Measure using myRIO
- Speed Measurement
- Vibration and Acceleration Measurement
- Stress and Strain Measurement
 - Measure using myRIO
- Saving (Sensor) Data using myRIO
- Attachment: Writing FPGA Codes




Position Sensors (4)

- Encoder
 - Converts motion into a sequence of digital pulses.
 - By counting bits, pulses can be converted to relative or absolute position measurements.
 - Can be linear or rotary.
 - Usage example:
 - Track the position of motor shaft in permanent magnet brushless motors.
 - Makes use of proximity sensor for the digital pulses.



Rotary Optical Encoder
https://commons.wikimedia.org/wiki
/File:Encoder.jpg











Photo emitter-detector pair for Proximity Sensing





Distance Measuring – Sharp GP2D

Fig.1 Internal Block Diagram




Fig.2 Internal Block Diagram








Photo-Sensing







Sensor Testing With MAX (Measurement & Testing Explorer)












Next let's look at another optical encoder: Clockwise




• Finally let's look at hall-effect encoder: Clockwise








- How to determine distance travelled? By counting the edges!
 - E.g. from datasheet, the encoder gives 100 PPR (Pulses per revolution).
 - If use only rising edge of channel A: 100 PPR → 3.6° per pulse.
 - If make use of both rising and falling edges on channel A, the resolution is increased by two (x2 logic): 3.6° / 2 = 1.8° per pulse.
 - If makes use of both rising and falling edges on both channels, the resolution is increased by four (x4 logic): 3.6° / 4 = 0.9° per pulse.
 - Cumulative sum of the counts = total distance travelled (Position).






- How to determine absolute position?
 - Note: total distance travelled gives only the <u>relative</u> position from where we started counting, e.g. after shut down and restart of device.
 - To obtain an <u>absolute</u> position, often there is a third signal (called "Index")
 which yields only one pulse per revolution, which can be used as the zero
 position.






- How to determine direction? We know that:
 - for CW rotation, B is delayed.
 - For CCW rotation, A is delayed.



- Detect rising edge of one channel, and check status of the other channel.
 - E.g. in x1 logic:
 - A rises & B = $0 \rightarrow CW$
 - A rises & B = 1 → CCW



What about x4 logic?




- At any of the rising and falling edge of A or B,
 - If A(now) != B(just now), then CW.
 - If A(now) = B(just now), then CCW.



Use myRIO to read in Encoder


- In this section, we will create a VI to read and interpret the encoder signals.
- Connect myRIO to the PC via a USB cable.
- PC will automatically detect myRIO and the following dialogue will pop up:
 - Choose "Go to LabVIEW 201x".





Use myRIO to read in Encoder

LabVIEW will be started.




Click on "Create Project"



Using Templates


 There are templates for blank project, myRIO project and myRIO custom FPGA projects.



· Choose blank project.




- You will see the project window.
- Right click on "Project: Untitled Project 1" → Save as → "Encoder".






Right click on Project Encoder → New → Targets and Devices



- Existing target or device:
 - Discover an existing target or device.
 - Or specify a target or device by IP address. (myRIO's IP is 172.22.11.2)
- Click on the "+" sign before myRIO.




• The project tree now looks like this:






- Right click on "NI-myRIO-1900..." → New → VI
- A VI will open.
- Save it as RT.vi.
- Now we are ready to program the VI for reading digital inputs.





- Recall that encoders give digital pulses which can be used for calculation of relative position, and also for determining the direction of motion.
- LabVIEW provides an FPGA function for interpreting the encoder signals.
- Let's create this VI:






- Your motor (RobotGear SKU-003141) has an integrated encoder.
- It also has 6 wires which are used as follows:

Colour	Meaning
Red	Motor +
Black	Motor -
Green	Encoder GND
Blue	Encoder Vcc (e.g. 5V)
Yellow	Encoder A Output
White	Encoder B Output




myRIO's datasheet shows the following port configuration:






• Therefore, please connect your motor with myRIO as follows:



Motor wire	Connect to
Red	Battery +
Black	Battery -
Green	myRIO GND
Blue	myRIO 5V
Yellow	myRIO DIO 11
White	myRIO DIO 12



Run the LabVIEW Program and you should see the following result:



- The code shows the counter value, as well as the direction.
- You can also press reset to bring the counter back to zero.




 Using myRIO's built-in encoder function, a total of four encoders can be supported:



One at MXP B


Two at MSP C




- If you need more than 4 encoders in any other mechatronics / robotics project, then you need to write your own encoder code.
- · Let's do this.




- Firstly, remember that encoder signals are just digital signals.
- So we can read signals A and B through any of the digital inputs.
- The next question is how to process the signals to do the counting.
- Start with x1 logic first:
 - Detect rising edge in A, and check status of B.
 - A rises & B = $0 \rightarrow CW$
 - A rises & B = $1 \rightarrow CCW$


















Connect your motor with myRIO as follows:




Motor wire	Connect to
Red	Battery +
Black	Battery -
Green	myRIO GND
Blue	myRIO 5V
Yellow	myRIO DIO 0
White	myRIO DIO 1








• If you are free, you may also try writing your own codes for the x4 logic:





- At any of the rising and falling edge of A or B,
 - If A(now) != B(just now), then CW.
 - If A(now) = B(just now), then CCW.



Content

- Position Measurement
 - Measure using myRIO
- Speed Measurement
- Vibration and Acceleration Measurement
- Stress and Strain Measurement
 - Measure using myRIO
- Saving (Sensor) Data using myRIO
- Attachment: Writing FPGA Codes



Speed Sensors

- To measure the speed of an object.
- Usage examples:
 - Measure the speed of DC motor, AC motor etc.
 - For speed control of machines etc.
 - Measure the speed of automated forklift.



Machine for printed electronics

https://commons.wikimedia.org/wiki/File: Elektronikdruck.jpg




Automated Forklift

https://commons.wikimedia.org/wiki/File: Forklift_AGV_with_Straddle,_courtesy_o f_Egemin_Automation_Inc..jpg



Speed Sensors (1)

- Encoder + derivation
 - This is one of the most widely used methods in Mechatronics.
 - Speed is defined as $\frac{\text{Change in Position}}{\text{Change in Time}} = \frac{\Delta p}{\Delta t}$
 - Let's first look at the an example of position signal, which is the cumulative sum of the edge counts:



 The position signal is discontinuous due to quantization → resolution of the encoder. Example: every level increase is 0.9°




Deriving Speed from Position

- There are two ways to calculate speed from position:
 - a) Make use of the constant quantization level *P*:
 - Determine the time duration between position increment.
 - Then

Speed₁ =
$$\frac{\Delta p}{\Delta t}$$
 = $\frac{P}{t_2 - t_1}$ Speed₂ = $\frac{\Delta p}{\Delta t}$ = $\frac{P - t_2}{t_4 - t_3}$

Speed₂ =
$$\frac{\Delta p}{\Delta t} = \frac{P}{t_4 - t_3}$$
 constant






Deriving Speed from Position

- Second method:
 - b) Make use of the constant sampling interval T of the discrete-time system.
 - At the sampling time instance, get the *P* value.

Then Speed₃ =
$$\frac{\Delta p}{\Delta t} = \frac{P_2 - P_1}{T}$$
 Speed₄ = $\frac{\Delta p}{\Delta t} = \frac{P_4 - P_3}{T}$ constant





Content

- Position Measurement
 - Measure using myRIO
- Speed Measurement
- Vibration and Acceleration Measurement
- Stress and Strain Measurement
 - Measure using myRIO
- Saving (Sensor) Data using myRIO
- Attachment: Writing FPGA Codes



Vibration and Acceleration Measurement

- To measure the vibration and acceleration of the device.
- Usage examples:
 - To detect sudden impact, e.g. Accelerometer detects hard disk drives fall towards ground and commands the read-write head to retract, preventing catastrophic scratch on the media surface.
 - Accelerometer can also identifies the direction of gravitational force, therefore used in smart phones for orientation of screen.



Hard Disk Drive Head Crash
https://commons.wikimedia.org/wiki/File:Hard
_disk_head_crash.jpg



Smart Phones
https://commons.wikimedia.org/wiki/File:Sam
sung_Galaxy_S6_edge%2B.jpg




Accelerometer

Frictionless / Not touching

 When the housing (attached to external object) accelerates, there is a relative motion between housing and the seismic mass.

$$x_r = x_i - x_o$$



- This relative motion is measured by the displacement transducer.
- Spring force: $F_k = k(x_i x_o) = kx_r$
- Damping force: $F_b = b(\dot{x}_i \dot{x}_o) = b\dot{x}_r$
- Newtons law for seismic mass: $m\ddot{x}_o = \sum F_{external}$

• Therefore:
$$m\ddot{x}_o = F_k + F_b = kx_r + b\dot{x}_r$$

• Which gives:
$$m(\ddot{x}_i - \ddot{x}_r) = kx_r + b\dot{x}_r$$

• Or:
$$m\ddot{x}_i = m\ddot{x}_r + kx_r + b\dot{x}_r$$

• Equivalently:
$$\ddot{x}_r + \frac{b}{m}\dot{x}_r + \frac{k}{m}x_r = \ddot{x}_i$$



Accelerometer

 The previous equation can be written in the standard 2nd order system equation:


$$\ddot{x}_r + 2\zeta\omega_n\dot{x}_r + \omega_n^2x_r = \ddot{x}_i$$

With natural frequency:

$$\omega_n = \sqrt{\frac{k}{m}}$$

And damping ratio:

$$\zeta = \frac{b}{2\sqrt{km}}$$



Amplitude Response of 2nd Order System

- If the accelerometer is designed such that the damping ratio is 0.707, the gain will be one for large frequency range.
- Then, if we operate the accelerometer within its bandwidth, we will have:

$$\omega_n^2 x_r = \ddot{x}_i$$


• That means, by measuring the relative displacement x_r , the acceleration of the housing (and thus object) can be calculated.



Displacement Transducer in Accelerometer

- There are various ways to measurement the relative motion in the accelerometer.
 - a) Potentiometer:
 - Seismic mass attached to wiper arm of potentiometer.
 - Suitable for low frequency (<30Hz) vibration measurement.
 - b) Piezoelectric:
 - Piezoelectric crystal: Deformation results in voltage generation.

Piezocrystal When housing / object accelerates, the seismic mass will press the piezo-crystal.





- Voltage generated is the measure of acceleration.
- The spring needs to be preloaded to keep mass in contact with the crystal.
- Good for up to 5kHz.



Detect Orientation by Accelerometer

- Accelerometer is used in consumer electronics (e.g. Smartphones) to detect orientation.
- At different orientation, the seismic mass is pulled by gravity differently.
- The mass will move to another position due to the gravitational force.
- This position is measured by the displacement transducer.
- By proper calibration, the orientation can be measured.







Content


- Position Measurement
 - Measure using myRIO
- Speed Measurement
- Vibration and Acceleration Measurement
- Stress and Strain Measurement
 - Measure using myRIO
- Saving (Sensor) Data using myRIO
- Attachment: Writing FPGA Codes



Stress and Strain Measurement

- To measure the stress and strain in a mechanical component.
 - Strain: Change in length per unit length

$$\varepsilon_{axial} = \frac{\Delta L}{L}$$
 Dimensionless




- Stress: Internal forces.
 - Related to strain: $\sigma_{axial} = E \varepsilon_{axial}$ E: Modulus of Elasticity
- Indirectly measure other quantities such as force and pressure.
- Usage example:
 - Force-controlled gripper, conforming to object shape or applied force.
 - Force-controlled robotic tooling, for polishing of workpiece at precise force.
 - https://www.youtube.com/watch?v=vX_6tOrFmEg
 - Coordinate Measurement Machines (CMM), for measurement of contours.
 Sensed force allows following of contour.
 - https://www.youtube.com/watch?v=y3WukuT41nc



Stress and Strain Measurement (1)


Electrical Resistance Strain Gauge:







How to use Strain Gauge

- Mounting:
 - Adhesively bonded to the surface of the part, whose surface strain is to be measured.
 - Short term measurement: Cyanoacrylate
 - Long term installation: Epoxy
- How does it find out the strain?







- When the component is loaded, the metal foil (which is bonded to the component surface) deforms.
- Resistance changes.
- By measuring the resistance accurately, the strain can be determined.

Deformation of Strain Gauge

https://commons.wikimedia.org/wiki/File:Strain GaugeVisualization.svg



Strain and Resistance

• Strain gauge datasheet: "Gauge Factor" *F*

$$F = \frac{\Delta R}{E_{\text{axial}}}$$

$$\Delta R : \text{Change in resistance}$$

$$R_0 : \text{Resistance at the unloaded state}$$


$$\varepsilon_{\text{axial}} : \text{Axial strain}$$

- Calculation example:
 - A 120Ω strain gauge with a gauge factor 2 experiences a change in resistance of 0.024 Ω . How much is the strain?

$$\varepsilon_{\text{axial}} = \frac{\frac{\Delta R}{R_0}}{F} = \frac{\frac{0.024}{120}}{2} = 0.0001$$



- The changes in resistance are usually very small \rightarrow hard to measure.
- To accurately measure the small changes in resistance, the "Wheatstone" Bridge" is commonly used.
 - Static balanced mode:
 - Fixed load is applied.
 - Potentiometer R_4 is tuned until the $V_{ex} \perp$ voltage between A and B is 0.
 - Therefore: $V_A = V_B \Rightarrow i_1 R_1 = i_2 R_2$
 - Also: $i_1 = i_4 = \frac{V_{ex}}{R_1 + R_4}$ & $i_2 = i_3 = \frac{V_{ex}}{R_2 + R_3}$



• Thus:
$$i_1 R_1 = i_2 R_2 \rightarrow \frac{V_{ex}}{R_1 + R_4} R_1 = \frac{V_{ex}}{R_2 + R_3} R_2 \rightarrow \frac{R_1 + R_4}{R_1} = \frac{R_2 + R_3}{R_2} \rightarrow 1 + \frac{R_4}{R_1} = 1 + \frac{R_3}{R_2}$$

$$\to \frac{R_1}{R_4} = \frac{R_2}{R_3} \to R_1 = \frac{R_4 R_2}{R_3}$$


R₁ accurately measured!



- The static balance mode is for fixed load.
- To measure a varying / dynamic load, we need the...

*R₁: Strain gauge

- <u>dynamic deflection operation</u>:
 - Load is NOT applied first.
 - Potentiometer R₄ is tuned until the voltage between A and B is 0.
 - The changes in the strain gauge resistance R₁ under time-varying load can be determined from changes in output voltage.




- The op-amp circuit is differential buffer follower, i.e. $V_{out} = V_{+} V_{-}$
- Here, $V_{out} = (V_{ex} i_2 R_2) (V_{ex} i_1 R_1) = i_1 R_1 i_2 R_2$
- The excitation voltage is related to the current as: $V_{ex} = i_1(R_1 + R_4) = i_2(R_2 + R_3)$
- (to be continued...)



- (...continued):
 - Solving for i₁ and i₂ in the V_{ex} equation, and substituting into the V_{out} equation, we get:

$$V_{out} = V_{ex} \left(\frac{R_1}{R_1 + R_4} - \frac{R_2}{R_2 + R_3} \right)$$

When the bridge is balanced, V_{out} is zero and R₁ has a known value.



*R₁: Strain

 When R₁ changes value, the above equation can be used to related the change in R₁ to the change in V_{out}.

$$\frac{V_{out} + \Delta V_{out}}{V_{ex}} = \frac{\Delta V_{out}}{V_{ex}} = \left(\frac{R_1 + \Delta R_1}{R_1 + \Delta R_1 + R_4} - \frac{R_2}{R_2 + R_3}\right)$$
 *The first equal sign is because V_{out} = 0


(to be continued...)




- (...continued):
 - After rearranging:

$$\frac{\Delta R_{1}}{R_{1}} = \frac{\frac{R_{4}}{R_{1}} \left(\frac{\Delta V_{out}}{V_{ex}} + \frac{R_{2}}{R_{2} + R_{3}} \right)}{\left(1 - \frac{\Delta V_{out}}{V_{ex}} - \frac{R_{2}}{R_{2} + R_{3}} \right)} - 1$$

- Thus: measure the change in the output voltage ΔV_{out}.
- Then: ΔR_1 can be determined.
- Finally, the strain can be determined from: F =
- If we assume $R_2 = R_3$, then $R_1 = R_4$ at balanced stage. It can be shown that:



*R₁: Strain gauge




 $\mathcal{E}_{\mathrm{axial}}$

Potentiometer




Increase Sensitivity

- The sensitivity of the bridge can be doubled by making both gauges active, but in different directions.
- For e.g. In a bending beam application,
 - One gauge (R₁) is mounted in tension
 - Another gauge (R₄) is mounted in compression.




• The output voltage is linear and approximately doubles the output of quarter-bridge circuit. $V = F \cdot C$





Temperature Compensation

- Temperature can affect the resistance of the strain gauge, which would lead to wrong measurement.
- To reduce the effect of temperature on the strain measurement:
 - Use two strain gauges in the bridge.
 - An active gauge (R₁) in the direction of strain.
 - A dummy gauge (R₄) one perpendicular to the direction of strain.



- Temperature changes are identifical in the two gauges, thus the ratio of their resistance does not change.
- Therefore the voltage V_{out} does not change due to temperature.



Piezoresistive Strain Gauge

- Apart from metal foil strain gauges, there are also strain gauges made of semiconductor material.
- They take advantage of the piezoresistive effect:
 - Change in resistance when mechanical strain is applied.

The change in resistance is greater than what can be explained by simple

geometric deformation.

 On the atomic scale, the change in volume causes the energy gap between the valence and conduction bands to change.

 Therefore it becomes harder for the electrons to be raised into the conduction band. Filled bands band Some conductor Panel Some conduct

Unfilled

Semiconductor Band Structure

Conduction

https://commons.wikimedia.org/wiki/File:Semiconductor_band_structure_(lots_of_bands_2).svg


- The change in resistance due to piezoresistance is approximately two orders of magnitude higher than in non-piezoresistive materials.
 - Therefore, semiconductor-based strain gauges are much more sensitive to deformation.



Derivation of Gauge Factor

- Previously, we saw that the gauge factor F is: $F = \frac{R_0}{R_0}$

- Let's derive this together.
- We approximate the metal foil grid lines as a single rectangular conductor.
- The total resistance is: $R = \frac{\rho L}{4}$



- Where ρ is the resistivity:
 - Resistance if L = 1m and $A = 1m^2$
- Then: $dR = \frac{L}{A}d\rho + \frac{\rho}{A}dL \frac{\rho L}{A^2}dA$ \Longrightarrow $\frac{dR}{R} = \frac{d\rho}{\rho} + \frac{dL}{L} \frac{dA}{A}$



$$\frac{dR}{R} = \frac{d\rho}{\rho} + \frac{dL}{L} - \frac{dA}{A}$$

- Because the cross-sectional area is: A = wh
- Therefore: $\frac{dA}{A} = \frac{w \cdot dh}{wh} + \frac{h \cdot dw}{wh} = \frac{dh}{h} + \frac{dw}{w}$

Derivation of Gauge Factor

• From Poisson's ratio (ratio of transverse and axial strain):

$$\frac{dh}{h} = -\upsilon \frac{dL}{L} \qquad \frac{dw}{w} = -\upsilon \frac{dL}{L}$$

- Therefore: $\frac{dA}{A} = -2\upsilon \frac{dL}{L} = -2\upsilon \varepsilon_{\text{axial}}$
- Substituting back into $\frac{dR}{R} = \frac{d\rho}{\rho} + \frac{dL}{L} \frac{dA}{A}$ gives: $\frac{dR}{R} = \frac{d\rho}{\rho} + (1 + 2\upsilon)\varepsilon_{\text{axial}}$
- Dividing through $\varepsilon_{ ext{axial}}$ gives:

$$\frac{dR/R}{\mathcal{E}_{\text{axial}}} = \frac{d\rho/\rho}{\mathcal{E}_{\text{axial}}} + \underbrace{(1+2\upsilon)}_{\text{due to change in length and area}}$$



Force Measurement

- Load cell is a sensor used to measure force.
- It contains an internal flexure element, usually with several strain gauges mounted on its surface.

 The flexural element's shape is designed so that the strain gauge outputs can be easily related to the applied force.



Compression Load Cell
https://commons.wikimedia.org/wiki/File:
Silomer_100kN.jpg



Double Beam Load
Cell

https://commons.wikimedia.org/wiki/File:DoubleBBeam WZ.png




S Load Cell

https://en.wikipedia.org/wiki/File:S Load Cell.PNG




- Just now, we also introduced the quarter Wheatstone bridge, and then the half Wheatstone bridge.
 - It was mentioned that the half bridge would have twice the sensitivity of the quarter bridge.



R₄: Potentiometer




• By using four strain gauges, we have a "Full bridge" and it doubles the sensitivity of the half bridge".



 Most load cells (including the one provided in project i.e. TAS606) has this full bridge built into it.



- Nevertheless, even with full bridge circuit, the potential difference between A and B could still be too small.
- Therefore we need to amplify it.
- Use the following differential amplifier circuit:





Assessment all the states all for a state and a

- Assume at unloaded state, all four strain gauges have the resistance R.
- Then: $V_{out} = \frac{R_G}{0.5R} V_{AB}$
- Choose appropriate R_G to get high enough gains.



- For TAS606, R has been measured to be around 360 Ohm.
- R_G is chosen to be 1M Ohm, so the gain is 5555.
- The operational amplifier is an LM358, and is connected as shown:






- Now let's set up a project in LabVIEW to read in the force sensor signals.
- As practice, let's start all over again.
- Unplug and plug-in myRIO device again.
- On the pop-up menu, choose "Go to LabVIEW 201x".






Click on "Create Project"






Choose blank project.






- You will see the project window.
- Right click on "Project: Untitled Project 1" → Save as → "AnalogInput".






Right click on Project AnalogInput → New → Targets and Devices



- Existing target or device:
 - Discover an existing target or device.
 - Or specify a target or device by IP address. (myRIO's IP is 172.22.11.2)
- Click the "+" sign before myRIO.




• The project tree now looks like this:






- Right click on "NI-myRIO-1900..." → New → VI
- A VI will open.
- Save it as RT.vi.
- Now we are ready to program the VI for reading analog inputs.






• Next, create the following VI in RT.vi:



Press the force sensor and you should be able to see the values in the


waveform chart varying.






- We may be able to calculate the theoretical values of V_{out}, but it is easier and more accurate to do our own calibration.
- Put objects of known mass on top of the force sensor and note down the value. E.g.

Mass (gram)	V _{out} (V)
600	0.25
800	0.45
1000	0.675
1100	0.9
1300	1.15
1500	1.9
1700	2.15





- It is hard to put objects on top of 1 load cell.
- So you may consider doing this:



• From the best fit curve, we can calculate the force applied onto the force sensor, based on the measured V_{out}:

$$V_{out} = 0.0018 \times m - 1.0113$$

$$m = \frac{(V_{out} + 1.0113)}{0.0018} \text{ in gram}$$


$$= \frac{(V_{out} + 1.0113)}{0.0018 \times 1000} \text{ in kilogram}$$

$$F = mg$$


$$= \frac{(V_{out} + 1.0113)}{0.0018 \times 1000} \times 9.8$$



We can therefore update our RT.vi as follows:



 Run the code, and you will see the force value changes when you press the force sensor. Note: All the sensors + Op-Amp combinations are different. Do not use the values on this slide for your project!






Content

- Position Measurement
 - Measure using myRIO
- Speed Measurement
- Vibration and Acceleration Measurement
- Stress and Strain Measurement
 - Measure using myRIO
- Saving (Sensor) Data using myRIO
- Attachment: Writing FPGA Codes




Let's use the AnalogInput project again, but now with logging of data.






The Write the Measurement File express VI has been configured as follows:



Note: In this example, data is to be saved onto desktop.




Now, run the VI and turn the potentiometer.



- After a while, press the stop button.
- Now, try to look for the measurement file on the desktop.
 - It's not in the designated folder!
 - · Where is it?




The following diagram shows the NI myRIO file system:



The data is actually saved in the Solid State Hard Disk Drive of myRIO.




To access the data, go to Computer.



· Click "Map network drive".




- Choose any available drive (e.g. R for myRIO).
- Key in the folder as shown.
- Uncheck "Reconnect at logon".
- Check "Connect using different credentials".
- Click Finish






- A Windows Security dialog will pop up.
- Key in username as "admin".
- Password is empty.






Now the folder appears and you can look for the measurement file.






After getting the file, you can copy it from myRIO into your PC.





 When you go to Computer again, you will see that a new drive (R) is created.






- In case the network drive feels slow, e.g. when opening folder, adding file etc.
 - Go to Control Panel
 - Select Network and Internet
 - Choose Internet Option
 - Under "Connections" Tab, click LAN Settings
 - Uncheck Automatically Detect Settings



One thing you would notice is that the x_value (time) is not exactly 10ms


apart.



 This is because the while loop with "wait (ms)" is only a software timer and is not absolutely accurate.




- Now, pop up on the while loop and click "Replace with Timed Loop".
 - Remove "wait (ms)".



- The timed loop uses hardware clock and is accurate.
- Also, timed loop has higher priority than other parts of the VI, thus guaranteeing real-time performance.




Double click on the top left box, and you will see the following dialogue.



- We leave the timing source as 1 kHz.
- Change the period to 10ms.
- Priority (here 100) means the priority of THIS timed loop relative to other timed loops, if exist.



- Run the VI again, and get the file from myRIO SS hard disk drive.
- Now, the x-values are much more consistent with the desired 10ms interval.





Thank you!

Reminder: Please redesign gripper before next week's class. Save ALL the individual parts into .STL format



Content

- Position Measurement
 - Measure using myRIO
- Speed Measurement
- Vibration and Acceleration Measurement
- Stress and Strain Measurement
 - Measure using myRIO
- Saving (Sensor) Data using myRIO
- Attachment: Writing FPGA Codes




Attachment: Encoder - FPGA

- After getting to know the basics of coding in FPGA, let's do something more exciting.
- We will create a code to read in encoder signals (in digital form) to:
 - Calculate the distance travelled
 - Determine the direction



Recall: How to Use Pulse Signals


- How to determine distance travelled? By counting the edges!
 - E.g. from datasheet, the encoder gives 100 PPR (Pulses per revolution).
 - If use only rising edge of channel A: 100 PPR → 3.6 per pulse.
 - If make use of both rising and falling edges on channel A, the resolution is increased by two (x2 logic): 3.6° / 2 = 1.8° per pulse.
 - If makes use of both rising and falling edges on both channels, the resolution is increased by four (x4 logic): 3.6° / 4 = 0.9° per pulse.
 - Cumulative sum of the counts = total distance travelled (Position).





Recall: How to Use Pulse Signals

- How to determine direction? We know that:
 - for CW rotation, B is delayed.
 - For CCW rotation, A is delayed.




- Detect rising edge of one channel, and check status of the other channel.
 - E.g. in x4 logic:
 - A (now) not equals B (just now) → CW
 - A (now) equals B (just now) → CCW



Recall: Deriving Speed from Position

- There are two ways to calculate speed from position:
 - a) Make use of the constant quantization level *P*:
 - Determine the time duration between position increment.
 - Then $\operatorname{Speed}_1 = \frac{\Delta p}{\Delta t} = \frac{P}{t_2 t_1}$ $\operatorname{Speed}_2 = \frac{\Delta p}{\Delta t} = \frac{P}{t_4 t_3}$ constant






Recall: Deriving Speed from Position

- Second method:
 - b) Make use of the constant sampling interval T of the discrete-time system.
 - At the sampling time instance, get the *P* value.

Then Speed₃ =
$$\frac{\Delta p}{\Delta t} = \frac{P_2 - P_1}{T}$$
 Speed₄ = $\frac{\Delta p}{\Delta t} = \frac{P_4 - P_3}{T}$ constant






Encoder - FPGA


- As detailed in last week's attachment, please prepare your project to include RT.vi and FPGA.vi.
 - Project name "EncoderFPGA".
- In FPGA.vi, create the VI as shown in the next few slides, and compile when done.






Case 1: Edge detected





Case 2: Edge not detected, but previous time between edge detection is less than 0.5s






Case 3: Edge not detected, but previous time between edge detection is more than 0.5s



Encoder - RT

Create the VI as shown:



• Run the VI and you will be able to see the encoder signal.





Thank you, Questions





